




**Global Power**  
Products

## GenerLink – Getting Connected

### Smart Phone App:

- Download the GenerLink app.
- Locate the serial number of your GenerLink. The serial number is shown above a barcode and is located to the right of the inlet.
- Open the app and look for the Bluetooth device called “GL\_XXXXXX”, where XXXXXX is the serial number of your GenerLink and click connect.
- Every 30 seconds, the app will check the current state of your GenerLink. You will receive a notification every time a power source is restored or lost.
- You can manually check the status by clicking “Show Status”.



### Remote Indicator:

- Power on the indicator using the switch on the top of the device.
- The red light indicates the device is powered on.
- The status of the two power sources will automatically be shown.
- The indicator uses a 9V battery. We recommend only turning on this device during an outage to avoid draining the battery.
- Keep indicator box at least 4 feet off the ground to ensure proper communication.



**Bluetooth range is affected by distance and interference. Move closer to your GenerLink if you are unable to connect. The maximum expected range through a building is 150 feet.**

### Customer Service:

Phone: (800) 886-3837

Email: [info@globalpowerproducts.com](mailto:info@globalpowerproducts.com)